CONTACT-SNOW CONTROL SYSTEM



INSPIRED BY NATURE // DRIVEN BY THE ELEMENTS // FLYOZONE.COM



OZONEKITES

THE CONTACT-SNOW CONTROL SYSTEM OFFERS THE LATEST IN RELEASE FEATURES, A CLEAN CONTROL BAR DESIGN AND A SIMPLE EASY-TO-USE TRIMMING SYSTEM.




PUSH AWAY QUICK RELEASE

The control system features our Megatron push-away quick release with total flag out of the kite. The release handle is ergonomic with positive release forces for quick and easy release. Simple re-assembly saves time and gets you back up and riding faster.


TWO RELEASE MODES – The Megatron offers riders a choice of two release modes, the recommended Standard or the optional Expert mode.

- Standard mode offers 100% flag out in all situations by releasing the Megatron or letting go of the bar when un-hooked. It activates the all new Internal Re-ride Release System on the kite. The kite will stall and fall to the ground without any power. After reassembling the chicken loop you can launch your kite and ride again.
- Expert mode offers 100% flag out only when the Megatron is released whilst hooked in, allowing riders practicing handle passes to let go of the bar without releasing the kite to flag out (not recommended).





CONTACT-SNOW CONTROL SYSTEM



EASY FLYING LINE SORTING If your flying lines get twisted you can easily undo them from the bar leader lines by opening the larks head knot and removing the twists. No need to walk up to your kite NOTE: Activate the Internal Re-ride Release System by pulling the 5th line through the chicken loop and secure it at the spliced in loop approx 2m up the line before you undo any flying line from the bar leader lines. **RONSTAN ORBIT PULLEY** The smooth running Ronstan Orbit Pulley also prevents trim MAGNETIC TRIM HANDLE The Magnetic trim handle connects to a magnetic neoprene sock covering the clam cleat to reduce tangles when the trimmer is de-powered. HAND BRAKE HANDLE Easily land or reverse launch your kite using the Hand Brake Handle